

# OFFICE

(Industry Standard Dimension)

- Standard desk height ranges between 29" and 30" and the standard depth range is from 18" deep to 24" deep.
- Regular TFL and dovetail drawer boxes have pre-determine heights (6", 8", 9", 12") and depths (12", 14", 16", 18", 22"). Scooped dovetail boxes have their own heights (2", 3", 6", 8") and depths (12-5/8", 14-5/8", 16-5/8") but you can modify the width up to 36". Industry standard widths are 18", 24" and 30". Do not exceed overall height of 48" for drawer banks. TFL is available unassembled or assembled and dovetails are always assembled – default undermount soft-close slides at 50 lbs capacity.
- For letter or legal filing drawers you must use a drawer box height of 12.5"
- If you are adding upper cabinets above your desk, then leave an 18" opening in height before designing the cabinetry. Keep the depth of the upper cabinets between 12" to 14" in depth.
- Accessories are 14"D and with standard widths of 18", 24" and 30". Accessories have side-mounted slides.
- Fillers will be used in multi design walls for a cleaner install, eliminating the need for cutting materials, as the filler will be the only piece that needs modification.

## Obstructions

- Ceiling light may impact how high you can take the material.
- Baseboard heights, light switch, outlets, heating and air vents, electric panels, attic space, etc. are all items you must be mindful when taking your measurements. It is important you design around these items.
- When placing drawer boxes or slide-out accessories right next to a wall, be sure they clear door casing and baseboards and allow easy slide out. A filler may be necessary here.

